Dear Customer

◆**Never leave the camera and the battery in a car or on a car dashboard in the summer.**

- It may cause leakage of the battery electrolyte, a generation of heat, and may cause a fire and the battery to burst due to the high temperature.

◆**When you want to view pictures on a TV, check if [VIDEO OUT] on the [SETUP] menu is set as follows.**

- **NTSC: In Japan and North America**
  PAL: In Europe
  (The display may be distorted or may look colourless if you select the incorrect video out setting.)

◆**The camera may become warm during use. This does not cause a problem with the performance or quality of the camera.**

◆**In motion picture mode [🎞], when you set the picture quality to [30fpsVGA] or [30fps16:9], we recommend using a high speed SD Memory Card/SDHC Memory Card with "10MB/s" or greater displayed on the package.**

- Depending on the type of SD Memory Card/SDHC Memory Card, recording may stop in the middle.
- We recommend using Panasonic's SD Memory Card/SDHC Memory Card.
- This unit does not support MultiMediaCard for recording motion pictures.

When carrying the camera

Please use extra caution while carrying it.

- We strongly recommend you do not leave the camera in your pants pocket when you sit down or forcefully insert it into a full or tight bag etc. Damage to the LCD monitor or personal injury may result.
- Take care not to knock or drop the bag/case that you inserted the camera in as the shock may cause damage to the camera, lens or LCD monitor.
- Do not attach any other items to the wrist strap that's included with your camera. While being stored, that item can rest against the LCD monitor and damage it.
- Do not use a paper bag as it can easily rip causing the camera to fall and be damaged.
- We strongly recommend you purchase a good camera bag/case from your local dealer to protect your camera.